

Free Standing Guardrail

Part #: 10579

Instructions

Compliant with all applicable OSHA 1910 and 1926 Subpart M regulations.

(1) HitchClip® required per (1) Free Standing Guardrail. HitchClips® sold separately.

Minimum (2) Free Standing Guardrails required to set up complete system.

Compatible roof pitch: 0/12-12/12.



Until fully protected from all fall hazards by Free Standing Guardrail system or other fall prevention system, ALWAYS use a complete and compatible personal fall arrest system, as determined by a Competent Person. NEVER make connections to Free Standing Guardrail.

Installation:

1. Install all necessary HitchClips® according to manufacturer's instructions. HitchClips® must be perpendicular to leading edge of fall hazard. Recommended installation distance of HitchClip® from fall hazard is 3'. Ensure no part of Free Standing Guardrail will hang over fall hazard when installed. When used with Free Standing Guardrail, maximum spacing between HitchClips® is 8'.

2. Insert headpin of Free Standing Guardrail base into HitchClip® key hole attachment point, and ensure headpin fully locks into place.

3. Adjust Free Standing Guardrail post until vertical. Secure post with provided locking pin.

4. Install all toeboards by fully inserting board into provided slot. Secure toeboards at each end with 1--5/8" #7 screw. Toeboards must be 2" x 4" construction grade lumber or better.

5. Install all guardrails. Guardrails must be 2" x 4" construction grade lumber or better. Guardrails must overlap a minimum 12" at each end. Adjust post rungs as needed to allow for guardrail lapping.

Materials: aluminum.

UPC-A Code: 672421105796

