

Ladder Assist Part #: 15104

- 1. Read and fully understand instructions prior to use.
- 2. Install Ladder Assist to top rungs of your permanent ladder. Ensure Ladder Assist is positioned to one side of the ladder, not in the middle. Position Ladder Assist in such a manner that it does not impede your movement up or down the ladder, or obstruct roof access point.
- 3. Tighten (4) adjustment screws on Ladder Assist until snug. Ensure no risk exists for Ladder Assist to disengage from ladder.
- 4. Raise Ladder Assist post to its full upright and locked position. Ensure your access to the roof is unobstructed.
- 5. To lower Ladder Assist post, raise the release handle at the bottom of Ladder Assist, and lower post until access point will completely close.





WARNING

Ladder Assist is not meant for use as fall protection. Never tie off to any component of Ladder Assist. Make sure that Ladder Assist is securely mounted to your ladder prior to use. Inspect Ladder Assist before each use. Ensure that Ladder Assist spring mechanism is functional and that no fasteners are missing. Check unit for corrosion, rust, or any deformation. If an unsafe operational condition exists, remove this product from service and discard, or contact Guardian Fall Protection for further assistance.